


ASSEMBLY INSTRUCTIONS



IT IS NECESSARY TO INSTALL A RESISTIVE SPARK PLUG (EX. NGK WITH R, LIKE BR8HS) AND A RESISTIVE SPARK PLUG CAP.

ALL LBR ELECTRONICS ARE INTENDED FOR AGONISTIC USE, IN CIRCUITS OR PRIVATE ROADS.
RIDING ON PUBLIC ROADS IS PROHIBITED AS WELL AS ILLEGAL!

LBR RACING ELECTRONICS ASSUMES NO RESPONSIBILITY FOR THE USE OF ITS ELECTRONICS,
AND IS NOT LIABLE FOR DAMAGE TO THINGS OR PEOPLE.

EACH PRODUCT HAS A 6-MONTH WARRANTY, WHICH BEGINS ON THE DAY OF DELIVERY OF THE PACKAGE TO YOUR HOME. IT WILL BE THE RESPONSIBILITY OF THE BUYER TO VERIFY THE CORRECT FUNCTIONING OF THE CONTROL UNIT WITHIN 6 MONTHS OF DELIVERY. ANY REQUEST FOR REPLACEMENT OR ASSISTANCE THAT OCCURS AFTER 6 MONTHS WILL NOT BE COVERED BY THE WARRANTY, BUT WILL BE SUBJECT TO REPAIR FOR A FEE.

ANY MODIFICATION MADE TO THE CONTROL UNIT WILL VOID THE WARRANTY (EG. CUT THE WIRES ETC ...).

ANY DAMAGE CAUSED BY AN INCORRECT CONNECTION WILL NOT BE COVERED BY THE WARRANTY AND WILL REQUIRE PAID ASSISTANCE.

ANY ATTEMPTS TO OPEN A CONTROL UNIT WILL INVALIDATE THE GUARANTEE, AND NO ASSISTANCE, EVEN FOR A FEE, WILL BE CARRIED OUT ON SAID CONTROL UNITS.